




Mercedes-Benz

Accessories

Installation Instructions

Mobile telephone cradle  
Nokia 6310i, Nokia 6310 and  
Nokia 6210



Validity

These installation instructions are valid for vehicles with hands-free system 11 and the Nokia 6310i or 6310 mobile-phone models, as well as - under certain conditions - for the Nokia 6210 with BLS-2, BLS-2S, BLS-2N or BPS-2 batteries.

Parts included

- (1) Mobile phone cradle

Notes

Please contact a qualified specialist workshop if you encounter difficulties when fitting the mobile phone cradle. Mercedes-Benz recommends that you use a Mercedes-Benz Service Centre for this purpose.

The manufacturer reserves the right to change technical details from those shown in the illustrations contained in these installation instructions.

These installation instructions also refer to the vehicle Owner's Manual. Please keep it handy for reference.


© 2007, Daimler AG

10/03  
03F099-03

Contents


- Fitting the mobile phone cradle ▷ 3
- Inserting the mobile phone ▷ 4
- Hands-free mode display ▷ 5
- Removing the mobile phone ▷ 6
- Dismantling the mobile phone cradle ▷ 7
- Operating instructions ▷ 8

Fitting the mobile phone cradle




1. Press the mobile phone cradle (1) into the retainers on the existing mounting bracket (2), hold in place and slide the cradle (1) upwards until it clicks into place.

Inserting the mobile phone




1. Remove the rounded cover (3) on the back of the mobile phone (4).
2. Slide the lower end of the mobile phone (4) into the lugs (5) of the cradle (1).



3. Press the upper end of the mobile phone (4) into the cradle (1) until the sides of the mobile phone (4) engage in the cradle (1).


### Hands-free mode display

For the hands-free system to operate properly, the mobile phone has to be inserted and switched on, and hands-free mode has to be activated.



#### Nokia 6310i and Nokia 6310:


A small vehicle symbol is shown on the display (arrowed). If this symbol does not appear, remove the mobile phone (4) from the cradle (see the section entitled "Removing the mobile phone"), then insert it again.



#### Nokia 6210:

"Hands-free" mode is indicated on the display (arrowed). If this indication does not appear, remove the mobile phone (4) from the cradle (see the section entitled "Removing the mobile phone"), then insert it again.


### Removing the mobile phone



1. Press the release button (6) and while it is pressed remove the upper end of the mobile phone (4) from the cradle (1). Then remove the mobile phone (4) upwards out of the cradle (1).
2. Replace the rounded cover on the back side of the mobile phone.

### Dismantling the mobile phone cradle

1. Remove the mobile phone from the cradle (see the section entitled "Removing the mobile phone").



2. Press the release button (7) and keep it pressed. Slide the mobile phone cradle (1) downwards and remove it from the existing mounting bracket (2).

### Operating instructions

1. Please refer to your Mercedes-Benz vehicle Owner's Manual for operating instructions regarding the mobile phone cradle in connection with the factory-installed hands-free system (code 386/388).
2. The following operating instructions (points a, b and c) only refer to the retrofitted accessory solution of the Mercedes-Benz multi-functional steering wheel with hands-free telephone mode.
  - General operation of the hands-free system: The vehicle Owner's Manual explains how to operate the hands-free system via the multi-functional steering wheel and how to set the run-on time.
  - Displaying the full name or number: To display the full name, press the "+" button. To display the full number, press the "-" button.
  - Adjusting the volume: During a telephone call, the volume can be increased with the "+" button and decreased with the "-" button.