


Mercedes-Benz

Accessories

Installation Instructions

Mobile phone bracket Sony Ericsson K770i and T650i



© 2008, Daimler AG

03/08 03F013-08

Contents Fitting the cradle Inserting the mobile telephone ≥ 5 Operating instructions ⊳ 7 Speed-dial keys ⊳ 8 Removing the mobile phone ⊳ 9 Removing the cradle

2

Risk of accident

Please comply with the legal regulations of the country in which you are driving when you use the mobile phone inside the vehicle.

If it is legally permissible to use the mobile phone while driving, only do so when traffic conditions allow for it. You may otherwise become distracted from the traffic, which may lead to an accident in which you or others may be injured.

For safety reasons, while driving, only use the hands-free system to make calls.

When you are using the mobile phone via the hands-free system, drive with extra caution, close all windows and try to eliminate background noise.

Please pull over or park the car if you do not wish to use the handsfree system to make a call. Do not stop the vehicle or park where it is prohibited to do so.

Place the telephone module into the cradle only while the vehicle is at a standstill. You could otherwise be distracted and cause an accident.



Validity

These installation instructions are valid for vehicles equipped with a

- Mobile phone fitting with interface (Code 386) or
- Mercedes-Benz mobile phone (Code 388) or
- Mercedes-Benz hands-free multi-function steering wheel
- Each in conjunction with a Sony Ericsson mobile telephone K770i or T650i.

Parts included

(1) Mobile phone cradle

In the following text, this will be referred to as "cradle".

General notes

Please contact a qualified specialist workshop if you encounter difficulties when fitting the cradle. Mercedes-Benz recommends that you use a Mercedes-Benz Service Centre for this purpose.


The manufacturer reserves the right to change technical details from those shown in the illustrations contained in these installation instructions.

These installation instructions also refer to the COMAND and Audio Operating Instructions, the vehicle Owner's Manual and the mobile phone operating instructions. Please keep them handy for reference.

At high outside temperatures, the cradle can become very hot when in operation, as is the case with the vehicle interior itself.

The installation procedure is shown using the Sony Ericsson K770i mobile telephone as an example. Follow the same procedure to install the Sony Ericsson T650i mobile telephone.

Fitting the cradle




1. Slide the cradle (1) into the bracket (2) until it audibly engages.

4

When inserting the mobile phone in the cradle, do not press on the display. You could otherwise damage your mobile phone.

5



1. Insert the mobile phone (3) in the cradle (1) as shown.

Switching to hands-free mode


When the mobile telephone is in hands-free mode, a Bluetooth® headset cannot be used.

To connect the mobile telephone to the hands-free system of the vehicle, the following settings must be configured on the mobile phone:

- Go to Menu → Settings → Profiles \rightarrow In car \rightarrow More \rightarrow View and edit.
- 2. Go to Accessory \rightarrow New Acces $sory \rightarrow Car handsfree.$ The message Profile updated: In car appears.


Note

In the Settings menu, select Flight $\verb"mode" \to \verb"Don't" show.$




A small car symbol (arrow) appears on the mobile phone display (3).

Removing the mobile phone



1. Slide the locking tab (4) upwards and remove the mobile phone (3) from the

Removing the mobile phone cradle



Press the release button (5), slide the cradle (1) downwards and remove.

Transferring the phone book in COMAND or audio system

Transferring the phone book is not possible

Therefore, this mode should be deactivated. (Please refer to the mobile telephone opera-

Do not remove the mobile phone from the

It is not possible to access the phone book on the SIM card via the vehicle's hands-free system. The telephone entries of the SIM card may have to be copied into the telephone book of the mobile telephone. (Please refer to the mobile telephone operating instructions.)

Editing and creating phone book entries is not possible using COMAND or the audio system.

Operating instructions

For information on operating the mobile phone via the multi-function steering wheel and configuring the run-on time, refer to the COMAND or Audio Operating Instructions, or the vehicle Owner's Manual.

mobile phone, in COMAND or in the audio system. Combined SIM PIN input is not possible.

If there are too many text messages in the mobile phone's memory, it is possible that no text messages will be displayed by

Press the 🛨 or 📥 buttons to change

If the mobile phone uses a pre-paid system,



Activating the number blocking feature is only possible on the mobile phone. (Please refer to the mobile phone operating instructions.)

If the mobile phone is inserted, it cannot be switched off via the vehicle. Because of this, switching to an available twin SIM card is only possible if the mobile phone is switched off manually.

It is recommendable to switch off the mobile phone at least once a months. (Please refer to the mobile phone operating instructions.)

Speed-dial keys

Only for vehicles with mobile phone fittings with interface (code 386) or Mercedes-Benz mobile telephone (code 388): On some vehicle model series, it is possible to access the memory keys 2 to 9 via the buttons to in the COMAND or the audio system. To do this, you must assign the memory keys 2 to 9 according to your preferences. (Please refer to the mobile phone operating instructions.)

Note

The memory position is not displayed on some types of mobile phone. The corresponding telephone number is displayed by pressing a key between 2 and 9. If you want to store a different telephone number in memory positions 2 through 9, these should be renamed as needed on the mobile phone.

while in Flight mode.

ting instructions.)

cradle during the telephone book transfer.

The SIM PIN must be entered either on the

COMAND or the audio system.

the volume during a telephone call.

depending on the provider, you might not be able to make use of some of the hands-free system functions.